

ATARI PROGRAM EXCHANGE

Bruce E. Campbell

CHARACTER FUN

User-Written Software for ATARI Home Computers

CHARACTER FUN

by

Bruce E. Campbell

Program and Manual Contents (C) 1983 Bruce E. Campbell

Copyright and right to make backup copies. On receipt of this computer program and associated documentation (the software), the author grants you a nonexclusive license to execute the enclosed software and to make backup or archival copies of the computer program for your personal use only, and only on the condition that all copies are conspicuously marked with the same copyright notices that appear on the original. This software is copyrighted. You are prohibited from reproducing, translating, or distributing this software in any unauthorized manner.

TABLE OF CONTENTS

	Page
INTRODUCTION	
Background Description	1
Minimum RAM and Accessories	1
Contacting the Author	1
GETTING STARTED	
Loading CHARACTER FUN	2
The First Display Screen	2
Helpful Hints	2
PROGRAM CONTROL	
Keyboard Control Keys	3
Console keys	3
Joystick Controls	4
Start Position	4
OTHER PROGRAM OPTIONS	
Custom Character Set	5
Other Notes	5
Save/Load Screen Option	6
Sample Screens	7
RESOURCE CREDITS	7
QUICK REFERENCE SHEETS	A

INTRODUCTION

Background Description

CHARACTER FUN is designed primarily to introduce the inexperienced computer user to the functions of the ATARI 400/800/1200 keyboards. In addition, many of the fascinating capabilities of the ATARI 400/800/1200 computers are utilized to allow you to experience the color, sound, graphics, and input/output options your computer system can utilize.

I wrote this program to stimulate my pre-school children's interest in computers and to introduce them to the functions of the keyboard. The entire ATARI character set, including the ATARI Control Graphics characters, can be displayed on the screen by pressing the appropriate keys. In addition, once I realized how fascinated they were, I added the music, colors, joystick effects, and the Custom Character Set to keep their interest and to challenge their creativity.

I have been very pleased with how fast my children have learned about the computer. They spend much more time with this program, creating their own designs, than they ever spent on the other keyboard type programs I showed them. I certainly hope you and your children and friends enjoy using this learning tool.

Minimum RAM and Accessories

Required Accessories

- 48K RAM
- ATARI 810 Disk Drive

Optional Accessories

- Joystick Controllers

Contacting the Author

Users wishing to contact the author about CHARACTER FUN may write to 15434 S.W. 77th Court, Miami, Florida 33157.

----- GETTING STARTED -----

Loading CHARACTER FUN

1. Remove any program cartridge from the cartridge slot of your computer console. If cartridge is present, a message will be printed to remove the cartridge and restart.
2. Plug in joysticks into the first two ports. (Optional)
3. Have your computer turned off.
4. Turn on empty disk drive. Wait for red busy light (and disk drive motor) to turn off.
5. Insert the **CHARACTER FUN** diskette into disk drive with the label on the top right. Then shut the disk drive door.
6. Turn on your computer and your TV set. The program will load into computer memory and start automatically.

The First Display Screen

The first display screen prints the program title, **CHARACTER FUN**, in large letters above a smiling face. To exit this demonstration mode, hold down the **START** key until the screen clears. Once the screen clears, a happy face cursor will appear on a blue screen. The program will now put characters on the screen at the cursor position as you press the keys.

Helpful Hints

Since I wrote this program to help my children learn about the keyboard, if you are using this program with young children, I suggest giving them no instructions. I found my children really enjoyed experimenting with all the options. Then when they asked how to repeat some instruction, I showed them how.

For older computer enthusiasts, let them choose between experimentation and reading the instructions.

PROGRAM CONTROL

Keyboard Control Keys

CTRL arrow keys move the cursor to the next desired position.
CTRL CLEAR clears the screen and moves the cursor to the top left corner.
SHIFT CLEAR clears the screen and switches between a color foreground and no foreground color.
ESC switches between standard and Custom Characters.
CTRL ESC switches on and off the instruction text window at the bottom of the screen.
CTRL INSERT switches background and border color between black and white.
BACK S deletes character immediately preceding the current cursor position.
SHIFT DELETE clears the current cursor row.
RETURN positions the cursor at the beginning of the next line.
SHIFT CTRL RETURN enters the screen save and load program.
TAB key turns on/off background music.
SHIFT CTRL TAB removes cursor from and returns cursor to screen.
BREAK has been disabled.
SYSTEM RESET stops program and reloads the program from the diskette.
ATARI LOGO, CAPS, and SHIFT keys have their normal function.

Console Keys

START exits the demonstration mode. It also rotates the screen foreground colors.
SELECT switches between typing characters backwards or forward.
OPTION switches between typing characters upside down or right side up.
OPTION SELECT scrolls the screen to the right.
OPTION START scrolls the screen up.
SELECT START switches between a single color and multicolor foreground.
OPTION SELECT START switches between large characters (5 or 6 rows of 10) and small characters (10 or 12 rows of 20). This option clears the screen and resets all the options to the normal start position. Background music is turned on.

Joystick Controls

JOYSTICK #1: The joystick plugged into the first joystick port controls screen scrolling. Pushing the joystick in any of the eight directions scrolls the whole screen in that direction until the joystick is released. When the **FIRE** button is pressed, an explosion sound occurs and the screen image shakes.

JOYSTICK #2: The joystick plugged into the second joystick port controls the happy face cursor position. Pushing the joystick in any of the eight directions moves the cursor in the desired direction until the joystick is released. When the **FIRE** button is pressed, a phaser type sound is heard and a phaser 'star' is typed at the cursor position. A phaser shot is not allowed in the same position twice in succession.

Start Position

- + Large characters (5 rows of 10).
- + Instruction text window at bottom of screen.
- + Cursor at upper left corner, screen clear.
- + Solid blue foreground.
- + White background.
- + Standard character set.
- + Capital letters.
- + Characters right side up and forward.
- + Background music on (POPI Goes the Weasel).

OTHER PROGRAM OPTIONS

Custom Character Set

(See attached quick reference sheets.)

+ Small letters (caps key) - single character
Crazy Characters: spaceships, faces, bugs,
animals, flowers, stick figures.

+ Capital letters

Normal keys: Bottom three rows of keys
form several different large faces (see
Making Faces on quick reference sheets);

3rd row from bottom: Hats and Eyebrows
2nd row from bottom: Ears and Eyes
Bottom row keys: Mouths and Ties

+ Top Row Keys (normal and shift) - provide
additional graphics characters. (see Custom
Graphics Characters on quick reference sheets).

+ CTRL Key (See Trains, Trucks, and Cars and
House and Building on quick reference sheets)

2nd row from bottom plus 'L' and
semi-colon: form train cars.
2nd row from bottom (G,H,I,J only) form
cars and trucks.
Remaining 2nd row and bottom row keys:
Building blocks, windows, doors, roofs,
etc.

Other Notes

+ In the Standard Character Set, when the
letters A-G and a-g are typed, the corresponding
C-major musical notes are sounded.

+ The demonstration mode continues as long as
START is not pressed.

+ After the program is started, if no action is
detected (keys pressed or joysticks used) in 4
minutes, the program returns to the
demonstration mode.

Save/Load Screen Option

Note: Since your CHARACTER FUN program diskette is unpatched, you will need to provide another formatted diskette to store your screen data.

+ Enter this option by holding down the SHIFT and CTRL keys and pressing the RETURN key.

+ Choose from the four options (printed below the Saved Screen Directory):

1) SAVE 2) LOAD 3) DELETE 4) EXIT

+ **SAVE Option:** Requires 4 sectors for large characters, 16 sectors for small characters. (Refer to **FREE SECTORS** listed below **SAVE SCREEN DIRECTORY**). Follow the instructions to save your screen. If the new file name matches an existing file name, the new one will replace the existing one if you so direct. The **SAVE** Option returns to the screen display you saved.

+ **LOAD Option:** Enter the number of the file you want. (Refer to the **SAVE SCREEN DIRECTORY**). The **LOAD** Option returns to the requested screen display.

+ **DELETE Option:** Enter the number of the file to delete from your diskette. (Refer to the **SAVE SCREEN DIRECTORY**). You will be asked to confirm your **DELETE** choice before any action is taken. The **DELETE** Option returns to the **SAVE/LOAD** Option Menu.

+ **EXIT OPTION:** Returns to the screen display.

Notes: Most of the screen display options will return to their **START POSITION**. The following options will return to the mode in which the screen was left (when **SAVE**, **DELETE**, or **EXIT** Options used) or the mode in which the screen was saved (for the **LOAD** Option):

- Large/small character mode.
- Color or no foreground.
- Instruction text window
- Single or multicolor foreground.
- Standard or Custom Character Set.
- Black or White background and border.

In addition the background music status (on or off) will be maintained.

Sample Screens

Included with the CHARACTER FUN diskette are five sample screens. These samples can be loaded using the Save/Load Screen Option described on page 6. They are named PICTURE.1 - PICTURE.5 and will be listed under the Save Screen Directory. These five files are locked using the Disk Operating System and cannot be DELETED or written over by the CHARACTER FUN program.

RESOURCE CREDITS

CHARACTER FUN was written by Bruce E. Campbell using ATARI BASIC, an ATARI 800 Computer, and an ATARI 810 Disk Drive. The CHARACTER FUN program and program documentation Copyright is registered with the Library of Congress under the name of this author.

ATARI BASIC, the ATARI 400/800/1200 Home Computers, and the ATARI 810 Disk Drive are products of ATARI, Inc.

The distribution version of CHARACTER FUN was produced using copyrighted software products of Monarch Data Systems, Cochituate, MA 01778.

MAKING FACES




NOTES

- Hit "ESC" for Custom Characters.
- Use CTRL arrow keys to position blinking face (cursor).
- To get Making Faces parts, press the letter shown at left above the part you desire.

☐ SHIFT key must be pressed and held down for these characters.

CUSTOM CHARACTER SET

Trains, Trucks, and Cars



Houses and Buildings



Crazy Characters



NOTES

- Hit "ESC" for Custom Characters.
- Press the letter shown above the desired character.
- To get small letter characters, first press (and release) the "CAPS LOCK" key.

○ CTRL key must be pressed and held down for these characters.



GRAPHICS DESIGN

ATARI Control Graphics

NOTES												
<ul style="list-style-type: none">• To set the ATARI Control Graphics, use the normal character mode.• Hit "ESC" for Custom Graphics Characters.• Press the letter shown above the desired character.												
Q	W	Z	R	T	Y	U	I	O	P			
A	S	D	F	G	H	J	K	L	I			
		X	C	V	B	N	M	.				
<ul style="list-style-type: none">○ CTRL key must be pressed and held down for these characters.◻ SHIFT key must be pressed and held down for these characters.												

Custom Graphics Characters

1	2	3	4	5	6	7	8	9	0	<	>